

# AUTOMATIC PLUG ASSEMBLY MACHINE

Model: TP389A-AHSC-1



\* \* \*

# Instruction Manual

\* \* \*

## Plug Assembly Machine

1. Mechanism introduction -----	P2
2. Introduction of each station -----	P3
1 <sup>st</sup> station : Check of plug body -----	P4
2 <sup>nd</sup> station : Plug installation -----	P5
3 <sup>rd</sup> station : Spring installation -----	P7
4 <sup>th</sup> station : Check of spring -----	P9
5 <sup>th</sup> station : Pincer installation -----	P10
6 <sup>th</sup> station : Unload NG product -----	P13
8 <sup>th</sup> station : Unload goods by XY-Table robot -----	P14
3. Index rotary -----	P17
4. F.R.L -----	P18
5. Solenoid valve -----	P19
6. Operating procedure -----	P21
7. Change Plug type -----	P22
8. Operating panel -----	P23
9. Operation of automatic state -----	P24
10. The frame of HMI -----	P25

## Appendix :


The list of market finished products -----	P34
Electric control box -----	P38
Electric circle -----	P40
Instruction manual for amplifier of optical fiber -----	P58

## 1. Mechanism introduction :

Type : Plug Auto Assembly Machine


Electric Power : 220V 50HZ 1 phase

Pneumatic Source :  $5 \pm 0.5 \text{ kg/cm}^2$





## 2. Introduction of each station :



8 stations of index rotary :



- 1<sup>st</sup> : Check of plug body
- 2<sup>nd</sup> : Plug installation
- 3<sup>rd</sup> : Spring installation
- 4<sup>th</sup> : Check of spring
- 5<sup>th</sup> : Pincer installation
- 6<sup>th</sup> : Unload NG product
- 7<sup>th</sup> : Free
- 8<sup>th</sup> : Unload goods by XY-Table robot

## 1<sup>st</sup> station : Check of plug body

Reflex sensor

(Check of plug body, nothing for sensing is right)



(SNR25 , SNR24)



Fixed screw for settling

(To loose screw to adjust height of sensor)

2<sup>nd</sup> station : Plug installation






Clip up/down cylinder  
(LS7 , LS8)

Floating connector

Moving cylinder  
(LS9 , LS10)




(LS5 , LS6 , LS3 , LS4)

Clipping cylinder

Throttling cylinder  
(LS59 , LS58)

Stopping cylinder  
(LS54 , LS55 , LS56 , LS57)

Optical fiber on middle of plug vibrator  
Alarm when could not sense Plug  
(SNR26 , SNR28)





Optical fiber on end of  
plug vibrator  
To control Plug sorter  
(SNR27 , SNR29)


(LS1 , LS2)

Turning cylinder

**3<sup>rd</sup> station : Spring installation**








※ Notice :

Do not use manual operation to feed spring if whichever hole of mold is without plug at 3<sup>rd</sup> station. That could avoid spring to stick in pipe.

## 4<sup>th</sup> station : Check of spring




Probe up/down  
cylinder

(LS23 , LS24)  
Mag sensor of  
probe up/down  
cylinder


(SNR9 , SMR10 , SNR11 , SNR12)  
Approx sensor for check of probe

## 5<sup>th</sup> station : Pincer installation



Moving cylinder  
(LS30 , LS29)

Clip up/down cylinder  
(LS26 , LS25)



(LS28 , LS27)


Clipping cylinder

Clipping cylinder  
(LS33 , LS34)

Optical fiber at  
head of pincer  
vibrating conveyer  
(SNR14 , SNR13)



approx sensor on  
middle of pincer  
vibrating conveyer  
(SNR19 , SNR20)

throttling cylinder  
(LS31 , LS32)






## CCD Camera (Image processing device)





Electric control box

## 6<sup>th</sup> station : Unload NG product




## 8<sup>th</sup> station : Unload goods by XY-Table robot






Pallet pushing cylinder  
(LS19 , LS20)

Pallet up cylinder 1




Pallet up cylinder 1  
(LS47 , LS48)

Pallet up cylinder 2  
(LS49 , LS50)



Pallet position cylinder 2  
LS62 , LS63

LS60 , LS61  
Pallet position cylinder 1





Limit position sensor

SNR5

Home sensor

Limit position sensor

SNR6



X-Table



Limit position sensor

SNR10


Home sensor

Limit position sensor

SNR7

Y-Table


### 3. Index rotary



Motor of index

LS53

Limit switch



Inlet of lubricant


Window for  
checking lubricant

Outlet of lubricant

※ Notice :

To check the oil mark of R68 lubricant at random.  
Resupply it when oil is lower than red mark.

#### 4. F.R.L ( Filter + Regulator + Lubricator )



Using method :

Turn knob "A" to micro adjustment (counter clockwise) to drop oil about 10 drops then tight (clockwise) knob "A", weekly.

The oil R32 need fill around 70-80% and release the moisture often.

## 5. Solenoid valve

※To described solenoid valve in sequence from up to down as below:



1. Probe up/down cylinder at 4<sup>th</sup> station
2. Holding cylinder at 3<sup>rd</sup> station
3. Stopping cylinder at 3<sup>rd</sup> station
4. Throttling cylinder at 3<sup>rd</sup> station
5. Separating cylinder at 3<sup>rd</sup> station
6. Stopping cylinder at 2<sup>nd</sup> station
7. Clipping cylinder at 2<sup>nd</sup> station
8. Clip up/ cylinder at 2<sup>nd</sup> station
9. Moving cylinder at 2<sup>nd</sup> station
10. Throttling cylinder at 2<sup>nd</sup> station
11. Turning cylinder at 2<sup>nd</sup> station




1. Moving cylinder at 5<sup>th</sup> station
2. Moving cylinder at 6th station
3. Throttling cylinder at 5<sup>th</sup> station
4. Clip up/down cylinder at 5<sup>th</sup> station
5. Clipping cylinder at 5<sup>th</sup> station
6. Clip up/down cylinder at 6th station
7. Clipping cylinder at 6th station
8. Clip up/down cylinder at 8th station
9. Clipping cylinder at 8th station
10. Pallet pushing cylinder at 8th station
11. Pallet lock cylinder at 8th station
12. Pallet up cylinder at 8th station





Puffing spring at 3<sup>rd</sup> station



1 : Puffing Plug at Plug sorter  
2 : Gate cylinder at Hopper

1

2



Regulator of pressure for plug  
turning cylinder at 2<sup>nd</sup> station

0.15MPa

Regulator of pressure for  
throttling cylinder at 3<sup>rd</sup> station


0.15MPa

## 6. Operating procedure

- a. To set machine on ground firmly.
- b. To join pneumatic pipe to joint of F.R.L and adjust air source pressure over  $5\pm 0.5\text{kg/cm}^2$ .
- c. Connect electric power; watch the voltage is 220VAC 50HZ 1 phase.
- d. To install ground wire certainly.
- e. Put parts of work piece into each bowl feeder.
- f. Turn on the non-fuse power switch from inner of electric control box.
- g. Turn on the power switch on operating panel then the work pieces were lined up.
- h. Change suitable spacer into each hole of mold at index plate.(as page 14)
- i. Change suitable spacer at head of plug vibrating conveyer
- j. Turn to un-lock red button before push start button (green) on the bench.
- k. Push green button to start machine
- l. Push yellow button to pause machine.
- m. Push red button to emergency stop machine.
- n. There is warning alarm within machine running, to check machine and then push yellow button to reset.
- o. Push green button to re-start after shut fault out.


## 7. Change Plug type

a. Change suitable spacer into each hole of mold at index plate.




※ Use M5 screw to take out spacer in each hole. Clean each hole and spacer before installation.

b. Change suitable spacer at head of plug vibrating conveyer



## 8. Operating panel




- a. Power : Power switch for electric power ON/OFF control.
- b. Power lamp : The lamp was light when power ON.
- c. Buzzer : The buzzer could sound when machine action was wrong or NG stops.
- d. Adjustor rotary : The adjustor control speed of index rotary. Turn clockwise is quick speed.
- e. Red lamp : The lamp is light when machine is stop due wrong.
- f. Yellow lamp : The lamp is light when machine run normally.
- g. Green lamp : The lamp is light when machine is working standby.
- h. HMI : Manual and auto screen that is controller of every cylinder motion.  
It can show error information when electric control produce wrong.
- i. CCD Monitor : Display CCD inspecting image and condition.



## 9. Operation of automatic state

- a. Green button : Push green button to start or re-start machine running.
- b. Yellow button : The button has two kinds of function, one is Reset another is Pause.  
Reset function : When error or alarm or NG product occurs within running, push yellow button to stop alarm sound and reset machine.  
Pause function : Each station finished all action before stop when push yellow button any time.
- c. Red button : Push the red button to emergency stop. All of actions were stop immediately.  
All of semi-finished goods were NG at every station at the moment.  
To turn the head of button to right then push green button to re-start machine.




Red button

Green button

Yellow button

## 10. The frame of HMI (Human Machine Interface)




(Fig. A)

「The frame is AUTO state」

- ※ Push key of “
- ※ Push key “Short/Long Plug” to change type
- ※ Push key of “Plug Counter Reset” to set zero for counter of Plug
- ※ Push key of “Pallet Counter Reset” to set zero for counter of Pallet
- ※ Push key of “中文/English” to change language.
- ※ Push key of “Ending”, the 2<sup>nd</sup> station don't supply
- ※ PLUG right now. But other stations are working till finish.
- ※ Push key of “Spring ON/OFF” to change spring installing option.
- ※ Push key of “Timer Set” to jump to frame of (Fig. B)
- ※ Push key of “Alarm” to jump to frame of (Fig. K)
- ※ Push key of “Change Pallet” to change new pallet
- ※ Push key of “Manual” to jump to frame of (Fig. C)

「The frame is timer setting page」




(Fig. B)

----- Example -----

- ※ Plug left sorter delay to stop set 5sec : The left plug sorter was stopped if the optical fiber senses plug to exceed 5 sec on end of vibrator.
- ※ Plug right sorter delay to stop set 5sec : The right plug sorter was stopped if the optical fiber senses plug to exceed 5 sec on end of vibrator.
- ※ Plug sorter delay to start set 5sec : The both plug sorters were start if the optical fiber senses no plug to exceed 5 sec on end of vibrator.
- ※ Spring puff : The timer control time of spring puff into plug.
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)


PS. Above bring up 5 sec is for example that is not correct setting.



(Fig. C)

「 The frame is Manual state 」

- ※ Push key of “Plug” to jump to frame of (Fig. D)
- ※ Push key of “Spring & Check” to jump to frame of (Fig. E)
- ※ Push key of “Pincer” to jump to frame of (Fig. F)
- ※ Push key of “Reject NG” to jump to frame of (Fig. G)
- ※ Push key of “Reject NG” to jump to frame of (Fig. H)
- ※ Push key of “Home” to jump to frame of (Fig. A)



(Fig. D)

「 The frame is manual operation of Plug installation at 2<sup>nd</sup> station 」

- ※ “Operating” : The operating lock if any button key was pushed and without reset. Push “Manual” and “Home” key is useless in this moment.
- ※ The keys function is as below :  
 “Clip up/down”→Clip up/down cylinder control  
 “Clip”→Clipping cylinder control  
 “Move back”→Moving cylinder control to move back  
 “Move out”→Moving cylinder control to move out

“Turn back”→Turning cylinder control to move back

“Turn out”→Turning cylinder control to move out

“Throttle back”→Throttling cylinder control to move back

“Throttle out”→Throttling cylinder control to move out


“Stopper” →Stopping cylinder control

“Vibrator” →Vibrator start control to feed Plug

“Hopper L”→Gate cylinder control to feed left sorter

“Hopper R”→Gate cylinder control to feed right sorter


- ※ Push key of “Index” once then rotary turn one station.
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)



(Fig. E)

「 The frame is manual operation of Spring installation and Check at 3<sup>rd</sup> and 4<sup>th</sup> station 」

- ※ The keys function is as below :
  - “Throttle”→Throttling cylinder control
  - “Stopper”→Stopping cylinder control
  - “Plug holder”→Holding cylinder control
  - “Plug separate”→Separating cylinder control
  - “Probe up/down”→ Probe up/down cylinder control at 4<sup>th</sup> station
  - “Puff”→Puffing solenoid valve control
- ※ Push key of “Index” once then rotary turn one station.
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)




(Fig. F)

「 The frame is manual operation of Pincer installation at 5<sup>th</sup> station 」

- ※ The keys function is as below :
  - “Clip up/down”→Clip up/down cylinder control
  - “Clip”→Clipping cylinder control
  - “Move back”→Moving cylinder control to move back
  - “Move out”→Moving cylinder control to move out
  - “Throttle”→Throttling cylinder control
  - “Vibrator”→ Vibrator start control to feed Pincer
- ※ Pincer L OK/NG” →Display CCD checking result at left side.
- ※ Pincer R OK/NG” →Display CCD checking result at right side.
- ※ Push key of “Checking direction” once then CCD camera check Pincer once and show the result on above lattice.
- ※ Push key of “Index” once then rotary turn one station.
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)






(Fig. G)

「 The frame is manual operation of Reject NG products at 6<sup>th</sup> station 」


- ※ The keys function is as below :
  - “Clip up/down”→Clip up/down cylinder control
  - “Clip L”→Left clipping cylinder control
  - “Clip R”→Right clipping cylinder control
  - “Move back”→Moving cylinder control to move back
  - “Move out”→Moving cylinder control to move out
- ※ Push key of “Index” once then rotary turn one station.
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)




(Fig. H)

「 The frame is manual operation of Reject good products and Pallet motion at 8<sup>th</sup> station 」

- ※ The keys function is as below :
  - “Clip up/down”→Clip up/down cylinder control
  - “Clip”→Clipping cylinder control
  - “Fix pallet”→Fix pallet cylinder control
  - “Push pallet”→Push pallet cylinder control
  - “Up pallet”→Up pallet cylinder control
  - “Pos. up”→Position cylinder control to change type let pallet position move up.
  - “Pos. down”→Position cylinder control to change type let pallet position move down.
- ※ Push key of “Index” once then rotary turn one station.
- ※ Push key of “Servo teaching” to jump to (Fig. I)
- ※ Push key of “Manual” to jump to frame of (Fig. C)
- ※ Push key of “Home” to jump to frame of (Fig. A)



(Fig. I)



(Fig. J)

「 The frame is manual operation of X-Table /Y-Table Servo teaching at 8<sup>th</sup> station 」

※ The keys function is as below :

“Servo off”→To turn off power of servo motor

“Reset” →Push the key when servo motor error

“HPR”→Home position return

“START”→To start X-table move to target position.

“JOG+”→Push the key to let robot move along plus direction by JOG speed.

“JOG-”→ Push the key to let robot move along minus direction by JOG speed.

“Enter”→To store the setting data in memory of PLC

“Y-Table/X-Table” →To jump between frame of (Fig. J) and (Fig. I)

“P/N”→ The position number at present

“Position”→ The digital position at present

“JOG Speed”→ To change mode of Low or High speed for motor running.

“Target”→ To set the target position number.


“Begin ” →The digital position of begin that is position of jig of index rotary.

“X1,X2...Y1,Y2...”→The digital position of each hole of pallet.

※ Push key of “Reject Good” to jump to (Fig. H)

※ Push key of “Manual” to jump to frame of (Fig. C)

※ Push key of “Home” to jump to frame of (Fig. A)



(Fig. K)

「The frame is Alarm message」

※ The words display mean sensors would not sense in suitable position.

### Alarm message

HMI display	Explain
S2-LS1 NG	Error of LS1 mag sensor of turning cylinder at outlying pos. at 2nd station
S2-LS2 NG	Error of LS2 mag sensor of turning cylinder at home pos. at 2nd station
S2-LS3 or LS5 NG	Error of LS3 or LS5 mag sensor of clipping cylinder at home pos. at 2nd station
S2-LS4 or LS6 NG	Error of LS4 or LS6 mag sensor of clipping cylinder at outlying pos. at 3rd station
S2-LS7 NG	Error of LS7 mag sensor of clip up/down cylinder at outlying pos. at 2nd station
S2-LS8 NG	Error of LS8 mag sensor of clip up/down cylinder at home pos. at 2nd station
S2-LS9 NG	Error of LS9 mag sensor of moving cylinder at outlying pos. at 2nd station
S2-LS10 NG	Error of LS10 mag sensor of moving cylinder at home pos. at 2nd station
S2-LS54 or LS56 NG	Error of LS54 or LS56 mag sensor of stopping cylinder at outlying pos. at 2nd station
S2-LS55 or LS57 NG	Error of LS55 or LS57 mag sensor of stopping cylinder at home pos. at 2nd station
S2-LS58 NG	Error of LS58 mag sensor of throttling cylinder at outlying pos. at 2nd station
S2-LS59 NG	Error of LS59 mag sensor of throttling cylinder at home pos. at 2nd station

S3-LS11 NG	Error of LS11 mag sensor of Plug holding cylinder at outlying pos. at 3rd station
S3-LS12 NG	Error of LS12 mag sensor of Plug holding cylinder at home pos. at 3rd station
S3-LS13 NG	Error of LS13 mag sensor of throttling cylinder at outlying pos. at 3rd station
S3-LS14 NG	Error of LS14 mag sensor of throttling cylinder at home pos. at 3rd station
S3-LS15 NG	Error of LS15 mag sensor of stopping cylinder at outlying pos. at 3rd station
S3-LS16 NG	Error of LS16 mag sensor of stopping cylinder at home pos. at 3rd station
S3-LS17 NG	Error of LS17 mag sensor of Plug separating cylinder at outlying pos. at 3rd station
S3-LS18 NG	Error of LS18 mag sensor of Plug separating cylinder at home pos. at 4th station
S4-LS23 NG	Error of LS23 mag sensor of probe up/down cylinder at outlying pos. at 4th station
S4-LS24 NG	Error of LS24 mag sensor of probe up/down cylinder at home pos. at 4th station
S5-LS25 NG	Error of LS25 mag sensor of up/down cylinder at outlying pos. at 5th station
S5-LS26 NG	Error of LS26 mag sensor of up/down cylinder at home pos. at 5th station
S5-LS27 or LS33 NG	Error of LS27 or LS33 mag sensor of clipping cylinder at outlying pos. at 5th station
S5-LS28 or LS34 NG	Error of LS28 or LS34 mag sensor of clipping cylinder at home pos. at 5th station
S5-LS29 NG	Error of LS29 mag sensor of moving cylinder at outlying pos. at 5th station
S5-LS30 NG	Error of LS30 mag sensor of moving cylinder at home pos. at 5th station
S5-LS31 NG	Error of LS31 mag sensor of throttling cylinder at outlying pos. at 5th station
S5-LS32 NG	Error of LS32 mag sensor of throttling cylinder at home pos. at 5th station
S6-LS35 NG	Error of LS35 mag sensor of up/down cylinder at outlying pos. at 6th station



S6-LS36 NG	Error of LS36 mag sensor of up/down cylinder at home pos. at 6th station
S6-LS37 or LS51 NG	Error of LS37 or LS51 mag sensor of clipping cylinder at outlying pos. at 6th station
S6-LS38 or LS52 NG	Error of LS38 or LS52 mag sensor of clipping cylinder at home pos. at 6th station
S6-LS39 NG	Error of LS39 mag sensor of moving cylinder at outlying pos. at 6th station
S6-LS40 NG	Error of LS40 mag sensor of moving cylinder at home pos. at 6th station
S8-LS41 NG	Error of LS41 mag sensor of up/down cylinder at outlying pos. at 8th station
S8-LS42 NG	Error of LS42 mag sensor of up/down cylinder at home pos. at 8th station
S8-LS43 or LS45 NG	Error of LS43 or LS45 mag sensor of clipping cylinder at outlying pos. at 8th station
S8-LS44 or LS46 NG	Error of LS44 or LS46 mag sensor of clipping cylinder at home pos. at 8th station
S2-SNR7 or SNR8 NG	Error of SNR7 or SNR8 sensor due to no Plug at top pos. of vibrator at 2nd station
S5-SNR19 or SNR20 NG	Error of SNR19 or SNR20 sensor due to no Pincer from sorter at 5th station
S2-SNR21 or SNR31 NG	Error of SNR21 or SNR31 sensor due to no Plug from hopper at 2nd station
S3-SNR15 、 16 、 17 or 18 NG	Error of SNR15 、 16 、 17 or 18 sensor due to no spring from sorter at 3rd station
S1-SNR24 or SNR25	Error of SNR24 or SNR25 sensor due to finished plug could not take out at 1st station
S2-SNR26 、 27 、 28 or 29 NG	Error of SNR26 、 27 、 28 or 29 sensor due to no Plug at vibrator at 2nd station
S5-SNR13 or SNR14 NG	Error of SNR13 or SNR14 sensor due to no Pincer at top pos. of vibrator at 5th station
S8-SNR23 NG	Error of SNR23 sensor due to full pallet on rail at 8th station
S8-SNR30 NG	Error of SNR30 sensor due to no pallet on storehouse at 8th station
Error due to XY-Table begin	Error due to XY-Table could not at begin position at 8th station

S4-SNR9 NG	Error of SNR9 sensor due to no Spring in Plug at 4th station
S4-SNR10 NG	Error of SNR10 sensor due to no Spring in Plug at 4th station
S4-SNR11 NG	Error of SNR11 sensor due to no Spring in Plug at 4th station
S4-SNR12 NG	Error of SNR12 sensor due to no Spring in Plug at 4th station
S8 -LS21 NG	Error of LS21 mag sensor of pallet lock cylinder at outlying pos. at 8th station
S8 -LS22 NG	Error of LS22 mag sensor of pallet lock cylinder at home pos. at 8th station
S8-LS19 NG	Error of LS19 mag sensor of pallet pushing cylinder at outlying pos. at 8th station
S8-LS20 NG	Error of LS20 mag sensor of pallet pushing cylinder at home pos. at 8th station
S8-LS47 or LS49 NG	Error of LS47 or LS49 mag sensor of pallet up cylinder at outlying pos. at 8th station
S8-LS48 or LS50 NG	Error of LS48 or LS50 mag sensor of pallet up cylinder at home pos. at 8th station
S8-LS60 or LS62 NG	Error of LS60 or LS62 mag sensor of pallet position cylinder at outlying pos. at 8th station
S8-LS61 or LS63 NG	Error of LS61 or LS63 mag sensor of pallet position cylinder at home pos. at 8th station
S8-SNR2 NG for X-Table	Error of SNR2 sensor was at front limit position of X-Table
S8-SNR3 NG for X-Table	Error of SNR3 sensor was at back limit position of X-Table
S8-SNR5 NG for Y-Table	Error of SNR5 sensor was at front limit position of Y-Table
S8-SNR6 NG for Y-Table	Error of SNR6 sensor was at back limit position of Y-Table
S8-SNR22 NG	Error of SNR22 sensor due to no pallet on lock pos. at 8th station

## The list of market finished products

	<b>Appellation</b>	<b>Model</b>	<b>Supplier</b>	<b>Q'TY</b>
1 <sup>st</sup> station	Reflex sensor	HPJ-D21	YAMATAKE	2
2 <sup>nd</sup> station	Sorter	Plug	YI SHING	2
	Vibrator	C-180	YI SHING	2
	Controller of Sorter	POC-305	YI SHING	2
	Controller of vibrator	POC-305	YI SHING	1
	Optical fiber	FU-35FA	KEYENCE	4
	Amplifier of Optical fiber	FS-M1	KEYENCE	4
	Moving cylinder	CDM2F32-100A-C73	SMC	1
	SENSOR	D-C73	SMC	2
	Buffer of moving cylinder	SC1415-2-NC	DOYO	1
	Turning cylinder	CDRB1BW50-180S-R73	SMC	1
	SENSOR	D-R73	SMC	2
	Floating connector	KG1010T	STARAIR	1
	Throttling cylinder	MGPM40-25 -Z73L	SMC	1
	SENSOR	D -Z73L		2
	Clip up/down cylinder	MGTU-25-25-RP	Mindman	1
	SENSOR	DY-21R	SMC	2
	Clipping cylinder	MHZ220DN-M9BL	SMC	2
	SENSOR	D- M9BL	SMC	4
	Fixed position screw	PUST1060		2
	Approx sensor	B02G6515N0	SELET	2
	Bearing	TA2015		1
	Linear guideway	BR15X220	ABBA	2
	Block	BRH15B-Z0N	ABBA	2
	Stopping cylinder	CDQ2A16-10DM-A73L	SMC	2
	SENSOR	D-A73L	SMC	4
	Gate cylinder	CDRQ2BS20-90-A93L	SMC	1
	Regulator of pressure	AR20K-01BG	SMC	3


	<b>Appellation</b>	<b>Model</b>	<b>Supplier</b>	<b>Q'TY</b>
3 <sup>rd</sup> station	Holding cylinder	CDM2F32-50A-C73L	SMC	1
	SENSOR	D-C73L	SMC	2
	DU	DU1515	OIL	1
	Spring	WL2040	Tohatsu	1
	Bearing	LM-12UU	GHT	4
	Bearing	LMK-12LUU	GHT	2
	Stopping cylinder	CDQ2A16-10D-A73L	SMC	1
	SENSOR	D-A73L	SMC	2
	Throttling cylinder	CDQ2A16-10D-A73L	SMC	1
	SENSOR	D-A73L	SMC	2
	Floating connector	KG1010T	STARAIR	2
	Separating cylinder	CDQ2A16-30D-A73L	SMC	1
	SENSOR	D-A73L	SMC	2
	Sorter	Spring	YI SHING	2
	Controller of Sorter	POC-305	YI SHING	2
	Approx sensor	B01AN15N0	SELET	4
4 <sup>th</sup> station	Probe up/down cylinder	JASMB4-20-37	JAFU	1
	SENSOR	DY-11R	DOYO	2
	Approx sensor	MB526NFA	SELET	4
	Fixed ring	PSCCN3-6	MISUMI	8
	Spring	WR4-20	MISUMI	4
5 <sup>th</sup> station	Optical fiber	FU-66T2	KEYENCE	2
	Amplifier of Optical fiber	FS-N11N	KEYENCE	2
	Throttling cylinder	JASMB4-20-25	JAFU	1
	SENSOR	DY-11R	DOYO	2
	Approx sensor	MB526NFA	SELET	2
	Sorter	Pincer	YI SHING	2
	Vibrator	C-80	YI SHING	1
	Controller of Sorter	POC-305	YI SHING	2
	Controller of vibrator	POC-305	YI SHING	1
	Moving cylinder	CDM2F32-75A-C73L	SMC	1
	SENSOR	D-C73L	SMC	2




	<b>Appellation</b>	<b>Model</b>	<b>Supplier</b>	<b>Q'TY</b>
5 <sup>th</sup> station	Buffer of moving cylinder	SC1415-2-NC	DOYO	1
	Floating connector	KG1010T	STARAIR	1
	Clip up/down cylinder	MGTU-25-25	Mindman	1
	SENSOR	DY-21R	DOYO	2
	Clipping cylinder	MHZ220D- M9BL	SMC	2
	SENSOR	D- M9BL	SMC	4
	Linear guideway	BR15x160	ABBA	2
	Block	BRH15B-Z0N	ABBA	2
	TFT LCD Monitor	RA70	YAU-YIH	1
	LED illuminant	HB20-80/15	YAU-YIH	1
	CCD camera	ANM832CE	Panasonic	1
6 <sup>th</sup> station	Moving cylinder	CDM2F32-75A-C73L	SMC	1
	Floating connector	KG1010T	STARAIR	1
	Clip up/down cylinder	MGTU-25-25	mindman	1
	SENSOR	DY-21R	DOYO	2
	Clipping cylinder	MHZ220DN-M9BL	SMC	2
	Linear guideway	BRH15B-1N-Z0-L160	ABBA	2
8 <sup>th</sup> station	XY-Table	X200*Y300	RENDER	1
	Key wicker	TKP0320W24(2B)R50	PE-EI	20
	Chain	TKP0320W24(2B)PIA	PE-EI	1
	Chain	TKP0320W24(2B)PKA	PE-EI	1
	Servo motor	6CC401G-30EBWAS	TECO	2
	Driver	TSTA15C	MIRLE	2
	Clip up/down cylinder	MGTU-25-25	mindman	1
	SENSOR	DY-21R	DOYO	2
	Clipping cylinder	MHZ220DN-M9BL	SMC	2
	Pallet up cylinder	CDQ2B32-50DM-A73L	SMC	2
	Pallet pushing cylinder	MGTU40-250-PR	mindman	1
	SENSOR	RCI-3M	DOYO	2
	Pallet lock cylinder	MCGJ-12-25*15	mindman	1
	SENSOR	DY-12R	DOYO	2
	Reflex sensor	HPJ-D21	YAMATAKE	3
	Pallet position cylinder	MGPM25-20-Y59B	SMC	2

	<b>Appellation</b>	<b>Model</b>	<b>Supplier</b>	<b>Q'TY</b>
Else	Index rotary	80DF-8N-240R	KAOLU	1
	Motor of index	M5IK90U-CRV	PE-EI	1
	Speed reducer	G5U25K	PE-EI	1
	Speed controller	SS2I6X-CB	PE-EI	1
	Limit switch	TZ7141	TEND	1
	Driving pulley			1
	Passive pulley			1
	Belt			1
	F.R.L.	AC30-03DG	SMC	1
	Solenoid valve	SY7120-5LZE-02	SMC	21
	Solenoid valve	SY7220-5LZE-02	SMC	6
	Fixed base	SS5Y7-20-11	SMC	1
	Fixed base	SS5Y7-20-12	SMC	1
	Fixed base	SS5Y7-20-13	SMC	1
	PLC connecting wire	5CC8152	Delta	1
	HMI	DOP-A57CSTD	Delta	1

# Electric control box






1 2 3 4 5 6 7 8


※To described Controller in sequence from left to right as below:

1. Controller of Plug Sorter 1
2. Controller of Plug Sorter 2
3. Controller of Plug vibrator
4. Controller of Spring Sorter 2
5. Controller of Spring Sorter 1
6. Controller of Pincer Sorter 1
7. Controller of Pincer Sorter 2
8. Controller of Pincer vibrator





PLC I/O circuit




20101115


Date

20100501-18-1


NO.

Risepower Autotech Co., Ltd






Risepower Autotech Co., Ltd	NO.	20100501-18- 3	Date	20101115
-----------------------------	-----	----------------	------	----------




Risepower Autotech Co., Ltd	NO.	20100501-18- 4	Date	20101115
-----------------------------	-----	----------------	------	----------



Risepower Autotech Co., Ltd	NO.	20100501-18- 5	Date	20101115
-----------------------------	-----	----------------	------	----------







COM2


COM3


COM4


COM2

COM3


COM4




















Risepower Autotech Co., Ltd	NO.	20100501-18- 13	Date	20101115
-----------------------------	-----	-----------------	------	----------





Risepower Autotech Co., Ltd	NO.	20100501-18- 14	Date	20101115
-----------------------------	-----	-----------------	------	----------












Risepower Autotech Co., Ltd	NO.	20100501-18- 18	Date	20101115
-----------------------------	-----	-----------------	------	----------

# Instruction manual for amplifier of optical fiber

# KEYENCE

NPN / PNP

## Manual-Calibration Fiberoptic Sensor FS-M1(P)/M2(P)/M0 Instruction Manual




A "P" following the model number indicates PNP-output type.

### MAJOR FEATURES AND FUNCTIONS


#### 1. Ultra-long detecting distance

When the selector switch is set to TURBO, the FS-M series provides approximately double the detecting distance.



#### 2. Fine adjustment

The detecting distance changes linearly according to the number of trimmer turns.



#### 3. Simple wiring


- The expansion unit needs no power supply cable.
- Up to 16 expansion units can be connected to a single main unit.

### WARNING

- The FS-M1(P)/M2(P) are intended for target detection. Do not use these products in a safety circuit for protecting the human body.
- The FS-M1(P)/M2(P) are not explosion-proof. Do not use these products in an atmosphere where inflammable gas, liquid or powder is present.

### STRUCTURE AND PART NAMES

#### FS-M1(P) (Main unit)



#### FS-M2(P) (Expansion unit for one-line bus system)

Every control/indicator functions the same as a main unit.

Expansion connector

Output cable only.

#### FS-M0 (Expansion unit for zero-line bus system)

\* There is no control output cable for the FS-T0.

\* Use the FS-R0 (Output port unit) as the main unit. The FS-T1(P)/M1(P) cannot be used as the main unit.

#### Accessories

Instruction manual (x 1)

Sticker

[included in the FS-M2(P) only]

Resin screw-driver (x 1)

Mounting bracket (x 1)  
[included in the FS-M1(P) only]


End unit (x 2)  
[included in the FS-M2(P) only]

### SPECIFICATIONS

Model	NPN output PNP output	FS-M1 FS-M1P	FS-M2 FS-M2P	FS-M0
Light source	Red LED			
Sensitivity adjustment/ Mode selection	8-turn trimmer (with indicator)/ FINE/TURBO switch-selectable			
Response time	250 μs (FINE), 500 μs (TURBO)		410 μs to 1.2 ms <sup>1</sup>	
Operation mode	LIGHT ON/DARK ON (switch-selectable)			
Indicators	Output indicator: Red LED, Stable operation indicator: Green LED			
Timer function	ON-delay: 40 ms, OFF-delay: 40 ms, Timer OFF (switch-selectable)			
Output	Control output	NPN or PNP open-collector 100 mA max. (40 V max.) Residual voltage: 1 V max. <sup>2</sup>		
	Stability output	NPN or PNP open-collector 50 mA max. (40 V max.) <sup>3</sup> Residual voltage: 1 V max.		
Protection circuit	Reverse polarity protection, Over-current protection, Surge absorber			
Power supply voltage	12 to 24 VDC ±10%, Ripple (P-P) 10% max. <sup>4</sup>			
Current consumption	35 mA max.			
Ambient illumination	Candescent lamp: 10,000 lx max. Sunlight: 20,000 lx max.			
Ambient temperature	-10 to +55°C <sup>5</sup>			
Relative humidity	35 to 85%			
Vibration	10 to 55 Hz, 1.5 mm double amplitude in X, Y and Z directions for two hours			
Shock immunity	500 ms/s <sup>2</sup> (Approx. 50 G) in X, Y and Z directions, three times each			
Housing material	Body/Cover: Polycarbonate			
Weight (including 2 m cable)	Approx. 75 g		Approx. 40 g	Approx. 20 g

### CONNECTIONS


#### NPN



- To connect the FS-M1 to a voltage input device, provide a 4.7 k $\Omega$  resistor between the brown and black cables.
- When the stability output is not used, cut the orange cable at the root, or connect this cable to the 0 V terminal of the power supply.

1. The FS-M2 has the black cable only.

#### PNP



- To connect the FS-M1P to a voltage input device, provide a 4.7 k $\Omega$  resistor between the blue and black or orange cables.
- When the stability output is not used, cut the orange cable at the root, or connect this cable to the positive terminal of the power supply.

1. The M2P has the black cable only.

detection is done the stable operation indicator (green LED) is turned on.

1

Stability output




When several units are connected, the stability outputs of all the units are output from the FS-M1(P) main unit based on OR logic.

## MOUNTING AMPLIFIER


### ■ Mounting/Detaching the amplifier to/from a DIN rail or the mounting bracket.

Hook the claw located at the amplifier cable side onto the DIN rail, and then hook the front side claw to the rail while pressing the amplifier forward. To detach the amplifier, unhook the front claw by lifting the amplifier front side while pressing it forward.



### ■ Side mounting


Using the side holes of the supplied mounting bracket, fix the amplifier with the screws. [For FS-M1(P) only]



## MOUNTING SEVERAL AMPLIFIERS

### ■ Mounting several units

1. Mount amplifiers to a DIN rail one by one.
2. Slide one expansion unit toward another. Align the front claws of the amplifiers and push the amplifiers together until they click.
3. Fix the amplifiers together by pushing an end unit onto each end (The end units are included in the expansion unit).




### ■ Detaching amplifiers from DIN rail

1. Remove the end units.
2. Slide the expansion units apart, and detach them individually. (Do not detach multiple amplifiers connected together with end units.)



- When several units are connected, confirm the ambient temperature. (See "Specifications" on p. 1.)
- To connect several units, be sure to use a DIN rail and end units.
- To mount or detach several units, be sure to turn the power off.

- Do not remove the protective cover of the expansion connector on the outermost unit.




1. In addition to the FS-M1(P), the FS-T1(P) can also be used as the main unit for the FS-M2(P).
2. The FS-R0 is used as the main unit for the FS-M0. In addition to the FS-M2(P), the FS-T2(P) can also be used as the expansion unit.

The sticker on the right is included in the expansion unit. Apply this sticker near the sensor.




## CONNECTING FIBER UNIT

Tilt the quick-release lever, insert the fiber unit until it stops, and then lift the quick-release lever.



- To connect a fiber unit with a small diameter, use the adaptor included with the FU series.

Attach the adaptor to the fiber unit, fully insert the adaptor into the mounting holes of the amplifier, and then lift the quick-release lever.




If the fiber unit is improperly connected, the sensor cannot meet the specifications.

- The required adaptor is included in each model of the FU series. If an inadequate adaptor is used, the fiber unit cannot be properly installed.

Type	Shape	Applicable fiber unit
Adaptor A (OP26500)	For 1.3 mm diameter	FU-32/35FA/4F/43/63/63T/66/78/91/93
Adaptor B (OP26501)	For 1 mm diameter	FU-31/37/38/38V/48/59/68/75F/79/95

- To connect the coaxial reflective type fiber unit to the amplifier, connect the single-core fiber to the transmitter side, and connect the multiple-core fiber to the receiver side. (Connect the fibers according to the marking on the amplifier lateral side.)



### ● Mutual Interference Suppression Function

**Up to four sensors can be connected without being affected by light beams from the adjacent units.**


(When the TURBO mode is selected, up to 8 sensors enable stable detection without mutual interference.)

When several units are connected, the FS-M series alternates the light emission timing with up to four sensors so that the adjacent sensors' light beams do not affect detection.

- The FS-M series can be used together with the FS-T series (manual-calibration type).



When only a single unit is used, the mutual interference suppression function cannot be used.






## HINTS ON CORRECT USE

- To extend the cable length, use a cable with at least a 0.3 mm<sup>2</sup> cross-section area. Limit the length of cable extension to no more than 100 m. (To connect several units, contact Keyence for further information.)
- If the amplifier cable is placed together with power lines or high-voltage lines in the same conduit, detection error may occur due to noise interference, or the sensor may be damaged. Isolate the amplifier cable from these lines.
- When using a commercially available switching regulator, ground the F.G. terminal and ground terminal.
- Do not use the FS-M series outdoors, or in a place where extraneous light can enter the light receiving surface directly.
- During maximum sensitivity setting, the detecting distance may vary due to the difference in characteristics of each unit.
- If the wiring is incorrect, the unit may heat up, or the sensitivity setting may fluctuate. (See "Connections" on p. 1.)

## I/O CIRCUIT

### NPN


#### FS-M1



1. When the stability output is not used, cut the orange cable at the base, or connect this cable to the 0 V terminal of the power supply.


### PNP

#### FS-M1P




1. When the stability output is not used, cut the orange cable at the base, or connect this cable to the positive terminal of the power supply.

#### FS-M2




- Power to the FS-M2 is supplied through the FS-M1/T1.
- Power to the FS-M2P is supplied through the FS-M1P/T1P.

#### FS-M2P




## DIMENSIONS


### FS-M1(P)




### When the mounting bracket [included in the FS-M1(P)] is attached




### End unit [Included in the FS-M2(P)]




### FS-M2(P)



### FS-M0



### When several units are connected:



- The FS-T1(P)/M1(P)/R0 is mounted in the end unit.
- When using expansion units, be sure to use the end unit [accessory to the FS-R0, T2(P), M2(P)].

No. of units	L
1	9
2	18
3	27
4	36
5	45
6	54
7	63
8	72
9	81
10	90
11	99
12	108
13	117
14	126
15	135
16	144

When expanding an FS-R3, refer to the FS-R3 dimensional drawing.

# KEYENCE

Worldwide Headquarters  
KEYENCE CORPORATION  
1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,  
Osaka, 533, Japan  
PHONE: 81-6-379-2211 FAX: 81-6-379-2131

North American Headquarters  
KEYENCE CORPORATION OF AMERICA  
PHONE: 201-930-1400 FAX: 201-930-0088

European Headquarters  
KEYENCE UK LIMITED  
PHONE: 01908-696900 FAX: 01908-696777

German Headquarters  
KEYENCE DEUTSCHLAND GmbH  
PHONE: 0711-796061 FAX: 0711-7977799

Singapore - Malaysian Headquarters  
KEYENCE S & M PTE LTD  
PHONE: 222-4554 FAX: 222-4372

Korean Headquarters  
KEYENCE KOREA CORPORATION  
PHONE: 02-563-1270 FAX: 02-563-1271

© KEYENCE CORPORATION, 1996  
Printed in Japan

Specifications are subject to change without notice.